

WISCO INDUSTRIES INC.
REPAIR PARTS FOR MODEL 630**PART NO: DESCRIPTION:**

0016015 THERMOSTAT
(on/off switch-new style-says HI-MED-LOW)

00100 THERMOSTAT KNOB

0016119 ON/OFF SWITCH (old style unit)

0016030 *WIRE FOR ON/OFF SWITCH

0016031 *WIRE FOR ON/OFF SWITCH
*need 1 of ea. 0016030 & 0016031

009092 PILOT LIGHT

009551 WIRE

00448 CORD SET

00131 STRAIN RELIEF

0016000 HEATING ELEMENT - 1500W

0016009 WING NUT

0016011 THREADED ROD

0016241 BAG OF PARTS
(incl. threaded rod, wing nut, disc w/nut assy & hex nut)

0016017 SUPPORT BRACKET

0016018 CLEANOUT TRAY

0016220 INNER & OUTER SHROUD ASSY

0016245 GRILL STAND - COMPLETE ASSY (Incl. stand & #0016241)

00116 THUMB NUT

00129 INTERNAL WIRE - 13-1/2"

00176 INTERNAL WIRE

0018032 FEET

00475 RUBBER INSERTS FOR FEET

00140 WIRE NUT

00150 #8 X 3/8" SHEET METAL SCREW

00151 #10-24 X 1/4" ROUND HD SCREW

009124 # 10 LOCKWASHER

0016002 GRILL ONLY (stand)

0016012 CARTON

0016239 10-1/2" ADAPTER DISC (for 14"-16" pizzas)

0016240 3-1/2" ADAPTER DISC (for 6"-8" pizzas)

0016244 DISC W/ NUT ASSY (for 10" - 12" pizza)